

# Instructions

## Ford Radius Rod Bushing

**N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.**

1. Raise vehicle evenly and safely support.
2. Remove front wheels.
3. Loosen front bushing bolt, then proceed to loosen/disconnect Radius arm ball joint - careful of thread.
4. Remove arm from vehicle.
5. The OE bushing will need to be pressed out with a Press - we suggest a workshop do this. Alternatively, wear appropriate safety gear.
6. Once bushing removed, check eye-ring is clean of any burrs.
7. Push supplied bushings in place.
8. Using supplied grease, grease bushing ID and face.
9. Insert supplied tube - note hole offset towards vehicle hub.  
- refer image below.
10. Re-fit arm to vehicle, tighten all bolts to manufacturers specs.
11. Re-check all bolts after initial 100kms travelled.



**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.