

# Instructions

## Rack Bushings

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

### Install Guide

**Application** - Nissan D40  
R51 Pathfinder

**Contents** - 4x bushings 90158  
1x bushing 90157  
2x steel tubes  
Grease

1. Raise vehicle evenly and safely support.

**Note** - its possible to remove OE bushings with rack hanging in vehicle.

2. Proceed to disconnect the battery and remove the front wheels.
3. Remove the plastic under-covers.
4. Un-bolt rack from Sub-frame. Also disconnect ball joints.
5. The OE bushings do not have a steel outer shell - so they can be pulled out with a nut and bolt and large socket.
6. Once OE bushings removed, push in supplied bushings. Apply a small amount of grease to the bushing ID and face. Re-use OE hardware.
7. Re-fit vehicle sub-frame and carry out a wheel alignment.



OE bushings can be pulled out with a nut/bolt and socket.

**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.