

Fitting Instructions BHR69 & BHR69Z

WHITELINE

Redranger Pty Limited
4 Warringah Close, Somersby, NSW 2250 Australia
Ph: 61 2 4340 2355 Fax: 61 2 4340 2466
E-mail: sales@whiteline.com.au
A.B.N. 99 124 177 297

Flat out

Code: Z246

- Application: Holden Barina XC, 2001-ON, - rear sway bar.
(Refer catalogue for exact listing).
- Specification: BHR69 - 20mm non-adjustable full kit sway bar.
BHR69Z - 20mm 3 hole adjustable full kit sway bar.

Contents:

- | | | |
|-----|-----|--------------------------------|
| 1. | 2 x | D-bush |
| 2. | 4 x | Sway bar link bushes |
| 3. | 2 x | 3/8 inch * 2 inch long bolt. |
| 4. | 4 x | 5/16 inch Nyloc nuts. |
| 5. | 2 x | M10 Nyloc nuts. |
| 6. | 4 x | M10 nuts. |
| 7. | 2 x | 3/8 Nyloc nuts |
| 8. | 2 x | 3/8*1-1/4 flat washer - large. |
| 9. | 2 x | 3/8 * 7/8 flat washer - small. |
| 10. | 2 x | chassis bracket |
| 11. | 2 x | link "L" bracket |
| 12. | 2 x | single eye link |
| 13. | 1 x | grease bag |
| 14. | 2 x | D-bush bracket |
| 15. | 1 x | sway bar |
| 16. | 4 x | M10 Saucer washers |
| 17. | 4 x | 5/16 *3/4 flat washer. |

Fitting Instructions:

1. Raise the rear of the car, support on chassis safety stands, and remove wheels.
2. Support hub, disconnect shock absorber lower mount, lower hub and remove spring.
WARNING - Spring compressors may be required to relieve any compression on the spring.
3. Fit 'L' shaped bracket (11) to the lower shock absorber mounting bolt as in captions below.
4. Assemble single eye link according to pictures below.
5. Mount bracket (10) to the inside of the rear swing arm chassis mount. Use OEM bolt.
6. Refit wheels, and lower the vehicle. Further fitting must be done with the vehicle at normal ride height - drive on ramps are can be used.
7. Grease D-bushes (1) with grease (12) and fit onto the sway bar.
8. Mount the sway bar (14) onto chassis mounts (10).
9. Mount link (12) into hole in bracket (11).
10. Tighten all mounting hardware.



Warning: Please drive carefully while you accustom yourself to the changed vehicle behaviour.